



## Reviewing and canceling timers

To see a complete list of timers use the following procedure.

- 1 Press the MENU button. The menu displays.



- 2 Select the Timer Review option and press the right arrow button. A list of timers displays.



- 3 To cancel a timer, use the up or down arrow button to highlight the desired timer. Then use the right arrow button to select the Clear status in the far right column.

- 4 Press the SELECT button to cancel the timer.
  - If the timer is set for a PPV program, you see a message. Follow the directions on the screen.
  - If the timer is set for a program that was not purchased, the timer is canceled.