


# Using the Program Guide

From the program guide, you can get information about programs, select a program, set timers, and purchase programs. Additionally, you can view the program guide by theme and view the titles alphabetically. The following figure shows the program guide.



The program guide shows you the following:

- The station call letters and channel number of the currently highlighted program.
- The title, start and end time, rating, a brief description of the currently highlighted program, and symbols if appropriate. For symbols, refer to page 5.
- The program guide displays by time or you can select to view the program guide by theme or title.

- Regular programs display with a blue background; premium programs display in purple; Pay-Per-View (PPV) programs display in green. If you have set a timer for any program, it displays yellow and the type of timer symbol displays.

## Displaying the program guide

Press the GUIDE button. The program guide shows the time grid. The currently selected program is highlighted in the time grid.


*Note:* To display information in the program guide for a day ahead, press the DAY+ button. To return to the current day, press the DAY- button.

## Displaying the program guide by theme

- 1 In the program guide, press the GUIDE button until you see a list of themes.
- 2 Press the up or down arrow button to scroll through the list of themes.




- To view the list of program titles that fall within the theme highlighted, press the right arrow button and you will see a display similar to the following one:




- Press the up or down arrow button to scroll through the list. A program that is currently playing is marked with a dot in front of the title.

## Displaying the program guide by title

- In the program guide, press the GUIDE button until you see an alphabetical list of letters.



- Press the up or down arrow button to highlight the first letter of the program title for which you want to view information. (When a title starts with a number, such as 3rd Officer, scroll to *Other*.)
- To view the list of program titles that start with the letter you selected, press the right arrow button and a display similar to the following displays:



- To scroll through the list of programs, press the up or down arrow button. A program that is currently playing is marked with a dot in front of the title.

## Selecting a current program from the program guide

- 1 To display the program guide, press the GUIDE button.
- 2 Use the up or down arrow button to highlight the current program you want to view.
- 3 Press the SELECT button. The program guide disappears and the selected channel displays.

*Note: If you select a program that requires a PPV purchase or is blocked via parental control, you will have to take additional action that is indicated on the screen.*

## Viewing more information about a program

You can use the program guide to get additional information about a program.

- 1 In the program guide, use the arrow buttons to highlight the program for which you want more information.
- 2 Press the INFO button. Passport DCT displays an extended description of the selected program.




- 3 To exit the extended description and return to the program guide, press the EXIT button.

## Setting a timer on a future program from the program guide

You can use the program guide to set timers on future programs.

- 1 From the program guide, highlight a future program and press the SELECT button.



- 2 Use the up or down arrow button to highlight your selection preference. Use the right or left arrow button to designate how often it recurs.
- 3 Press the SELECT button.

A timer is set and the program displays yellow in the program guide. A symbol indicates the type of timer you set.

*Note: The View Channel Now option displays the current program in progress that is on the currently selected channel.*

## Exiting the program guide

To exit the program guide, press the EXIT button.