

COX HOMELIFE DEVICES BATTERY REPLACEMENT INSTRUCTIONS

DOOR AND WINDOW SENSOR



Visonic Brand



CR2 Battery (1)

- 1 Insert a small flathead screwdriver into the notch located on the magnetic side of the larger piece of the device.
- 2 Twist the screwdriver to pop off the sensor cover and set it aside.
- 3 Remove the old battery from inside the cover and dispose of it properly.
- 4 Insert one new CR2 battery, observing proper polarity.
- 5 Push the cover back on the sensor until it clicks into place.

COX HomelifeSM

Protect. Monitor. Control.