

COX HOMELIFE DEVICES BATTERY REPLACEMENT INSTRUCTIONS

SMART DOOR LOCK



Kwikset Brand



AA Battery (4)

- 1** Remove the interior cover of the door lock using the included hex key.
Note: you can find a replacement 3/32" hex key at your local hardware store
- 2** Lift the battery pack out of the lock by pulling up on the pack.
- 3** Remove the batteries from the battery pack and dispose of them properly.
- 4** Insert four new AA batteries into the battery pack.
- 5** Reinstall the battery pack, making sure the arrows on the DOOR indicator are pointing towards the door.
- 6** Secure the cover back on the lock using the hex key.

COX HomelifeSM

Protect. Monitor. Control.