

COX HOMELIFESM DEVICES BATTERY REPLACEMENT INSTRUCTIONS

SMART THERMOSTATS



ZEN BRAND



AA BATTERY (4)

- 1 Remove the faceplate of the thermostat by gripping the sides and pulling it away from the wall.
- 2 Replace all 4 AA alkaline batteries, observing proper polarity, and dispose of the old ones properly.
- 3 When done, place the faceplate back on to the thermostat.

COX HomelifeSM

Protect. Monitor. Control.