

# COX HOMELIFE<sup>SM</sup> DEVICES BATTERY REPLACEMENT INSTRUCTIONS

## GLASS BREAK SENSOR



SMC BRAND



CR123A BATTERY(1)

- 1 Use a Phillips screwdriver to remove the screw located at the bottom of the sensor.
- 2 Pry off the cover using your hand or a flathead screwdriver and set it aside.
- 3 Remove the old battery and dispose of it properly.
- 4 Insert one new CR123A battery.
- 5 Replace the cover by gently pushing it back onto the sensor until it clicks into place.

**COX** Homelife.

Protect. Monitor. Control.