

COX HOMELIFESM DEVICES BATTERY REPLACEMENT INSTRUCTIONS

WIRELESS KEYPAD



SMC BRAND



CR2 BATTERY (2)

- 1 Open the battery compartment.
- 2 Remove the old batteries and dispose of them properly.
- 3 Install two new CR2 lithium-ion batteries.
Note: It is important that you do not mix old and new batteries and use only new CR2 lithium-ion batteries.
- 4 Make sure the batteries are positioned correctly in line with the two positive (+) polarity signs that display above the battery compartment. Both batteries must be installed with the positive (+) side pointing upward.
Note: If batteries are installed incorrectly, the keypad may be damaged by a short circuit or by the battery overheating.
- 5 Snap the battery cover closed.
- 6 If tape was used to install the keypad on the wall, take extra care that the polarity markings are clear.

COX HomelifeSM

Protect. Monitor. Control.